



VHX-77C-CAP Dakota Digital VHX Instrument Installation For 1977-'90 Chevrolet Caprice/Impala 1984-'86 Pontiac Parisienne

Your new VHX-77C-CAP kit includes:



Installation

1. First, you will need to remove the stock gauge cluster; the procedure may vary depending on year of vehicle. Remove the five (5) screws and three (3) plastic push pins indicated in the photo. On the backside there are two (2) nuts towards the bottom that hold the cluster to the dash. Also disconnect the wiring harness, shift indicator cable, and speedometer cable. Retain the factory lens and screws for reassembly.



2. Remove the factory connector to allow clearance for the VHX system.



3. Attach the provided 36" CAT5 cable to the back of the VHX system and carefully route the other end to the control box mounting location.



4. Place the VHX system into the dash and align the cluster to sit straight and then secure the system from the back side of the dash using the two (2) provided nuts.





5. Secure the factory lens over the VHX system using the five (5) factory screws. You are now done mounting the VHX system; refer to the main manual for wiring instructions to complete the VHX installation.





4510 W. 61st St. N., Sioux Falls SD 57107 Phone: (605) 332-6513 Fax: (605) 339-4106 www.dakotadigital.com dakotasupport@dakotadigital.com