



56 Ford pickup kit installation instructions.

This sheet contains additional information not found in your system manual.

To install the gauges you will need the tools required to remove the original dash from your vehicle and silicone RTV or hot glue. You will not be using the original glass or the original gauge back plate.

1. Remove the original dash from the vehicle
2. Remove all of the original gauges from the instrument cluster. You should be left with just the front trim and mounting bezel.
3. Remove the new digital gauges from their packing material carefully.
4. Place the original bezel on a table with the front facing down.
5. Place the new digital display panel into the original bezel. The top, curved side should be placed in first. Next place the bottom side down into the bezel.
6. Move the display panel down so it is sitting tight on the bottom of the trim. The lens will align the gauges properly.
7. From the back side, place a 2" bead of RTV on the left side of the curved section, the top side of the curved section, and the right side of the curved section. This will secure the digital display panel to the original bezel.
8. After the RTV has had time to cure (this will take several hours) place the bezel back into the vehicle. It will mount in the same as it did before the digital gauges were installed.

⚠WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov



4510 W. 61st St. North
Sioux Falls, SD 57107
www.dakotadigital.com

Phone (605) 332-6513
Fax (605) 339-4106

dakotasupport@dakotadigital.com Copyright 2011 - Dakota Digital, Inc.